

Nº	CODE	DESCRIPTION
1	P-IW-12P-01	MAINTENANCE KIT

MAINTENANCE KIT:

- 7 rotor blades
- 1 Rear gasket
- 1 front gasket
- 1 anvil O-ring
- 1 anvil clip
- 1 air valve spacer-gasket

Parts not included in the maintenance kit are not supplied.

Not numbered parts are shown for illustration purpose only and are not available.

Available parts are supplied by kits but not individually.

For damages of parts not available, a renewal plan of a new P-IW-12C is quoted with a special discount if the broken unit is returned to our Irimo distributor for being analyzed & recycled

Click [HERE](#) or scan the below QR code to get the service manual:



P-IW-12P

